
Installation Diagram for 1/8" (3mm) Router Bit and Sleeve

Gerber FastFact # 5013

Supplied by: Gerber Service

Last Modified: October 25, 2001

Summary: This document provides a diagram illustrating bit, sleeve, and router collet assembly.

The 1/8" (3mm) sleeve is used to hold bits with a 1/8" (3mm) shank in a 1/4" (6mm) collet.

See the diagram below illustrating the installation of the router bit and sleeve into a router collet assembly. Make sure the slotted end of the sleeve faces down as shown.

Note: When using a Perske spindle be sure to snap the router collet into the collet nut before inserting the sleeve into the collet.

